

IMPORTANT

ALUMINUM FLYWHEEL TORQUE PLATE INSTALLATION

Clutch Masters' aluminum flywheels come complete with a steel torque plate to protect the aluminum surface of the flywheel from the crank bolts when torqued down. The torque plate should **ONLY** be placed on the front (pressure plate) side of the flywheel, **it is not a shim**.

After installation of a performance clutch and/or flywheel, you should manually test the clutch for proper adjustment and clearance before starting the engine. If you have any problems or concerns please contact our techs at **(909) 877-6800**, or **tech@clutchmasters.com**.

